



# Activboards



The board themselves need very little maintenance. Keeping them clean is really all they need on a recurring basis.

## Recommended Activboard maintenance:

- **Cleaning:** Periodic cleaning may be needed to clean off dirt, grime or even the stray pencil and dry erase pen marks. It is not a good idea to over-clean the board as this will reduce the effectiveness of the anti-glare coating applied to the surface of the board.
  - Use a clean rag and a non-abrasive, ammonia-free liquid cleaner.
  - Spray the cleaner on the rag and rub the board clean.
  - Repeat as needed (it may take a few cleanings over a period of time (like a month) to remove the marks completely.